


Arcadia Licensed Ports

Arcadia Licensed Ports are used by FreeSpeak beltpacks, HelixNet enabled channels and Dante interfaces. Licensed Ports allow your Arcadia deployment to be right-sized for your requirements at the time of order or field upgraded over time.


40



Beltpacks

FREESPEAK Wireless Intercom

One Beltpack per Licensed Port




24




HelixNet Enabled
Channels

HELIXNET Digital Wired Partyline

One Partyline Channel per Licensed Port




64



Dante Ports

DANTE Audio Network Interface

One Dante Port per Licensed Port



FREESPEAK

Wireless Intercom

Available in 1.9 GHz, 2.4 GHz and 5GHz frequency ranges. Allows modularly adding beltpack capacity and coverage with IP networked or E1 direct connected Transceivers. Wireless Beltpacks can have 5 to 9 keys configured to talk/listen to any Channel, Group, Port or Role on the system.

Note: Wireless transceivers, 4-wire and 2-wire connections do not require the use of Licensed Ports.

HELIXNET

Wired Networked Partyline

Allows network connected Beltpacks, Remote Stations or Speaker Stations to be added to Arcadia. The stations can have 2 or 4 keysets assigned to any HelixNet Enabled Channel on the Arcadia system.

Note: HelixNet Endpoint Keysets can only be assigned to HelixNet Enabled Channels and not to Groups or direct to interfaces.

DANTE

Dante 3rd Party Audio Networks

Enables easy interfacing to any input or output on the Dante network such as pre-fade microphones, paging zones, monitoring systems, audio processing, recorders, playback devices, for addition to any Arcadia Channel, Group or direct Key Assignment to FreeSpeak beltpacks.

Visit the Arcadia Knowledge Center for more information.



www.clearcom.com/arcadia-knowledge-center/

Find out how many Licensed Ports you need with the Arcadia License Port Calculator



www.clearcom.com/arcadia-calculator/

Clear-Com
AN HME COMPANY